

EXPANSION WEDGES

WOOD ACCESSORIES - PRODUCT INFORMATION

Expansion wedges - spacers.

- Spacers for different types of woodflooring installation.
- Leave a 5 - 10 mm gap between the wall and the installed floor (for Segno, 5 mm).
- It is important that the spacer wedges remain in place until the glue has dried.

Technical Information	Expansion Wedges
Itemcode	8790204
Description	Plastic spacer wedges
Pack size	1 x 50 (1 box = 50 pcs)
For more information see tarkett.com	

Wood is a living material, which means that a wooden floor that is fully glued to the substrate will move slightly (swell or shrink), depending on how the indoor climate changes during the year. For practical reasons, press down wedges between the floor and the wall to create an expansion joint of at least 5 - 10 mm. For a flooring installation of Segno it's advisable to leave a gap of 5 mm between the floor, wall and other fixed installations. It is important that the spacer wedges remain in place until the glue has dried, before removing them. Gluing to the substrate reduces the movement of wooden floors. This is recommended for laying a pattern, large surfaces, etc. The advantage of gluing is that it is possible to place fittings, such as kitchen fittings, stairs, walls, heavy objects or woodburning stoves directly on the floor.

Always refer to the latest installation instructions.

